

<u>LOT #</u>		<u>QTY</u>	<u>LOT #</u>		<u>QTY</u>
1	4 Office cubical partitions	1	24B	Gray cloth & metal chair	1
2	Wooden office desk	1	24C	Gray cloth & metal chair	1
3	Wooden office desk	1	24D	Gray cloth & metal chair	1
4	Metal & formica office desk	1	24E	Gray cloth & metal chair	1
5	Corner work center desk	1	24F	Gray cloth & metal chair	1
6	Wooden office desk	1	25A	Burgundy cloth padded metal chair	1
7	Wooden office desk	1	25B	Burgundy cloth padded metal chair	1
8	Wooden office desk	1	25C	Burgundy cloth padded metal chair	1
9	Round wooden table	1	25D	Burgundy cloth padded metal chair	1
10	Round wooden table	1	25E	Burgundy cloth padded metal chair	1
11	Round wooden table	1	25F	Burgundy cloth padded metal chair	1
12	Round wooden & metal table	1	25G	Burgundy cloth padded metal chair	1
13	Oval dinette set w/4 wooden chairs	1	26	Brown leather sofa	1
13A	Gray padded rolling chair	1	27	Brown leather loveseat	1
13B	Gray padded rolling chair with arm rests	1	28	Blue leather loveseat	1
14	2 Yellow padded chairs	1	29	Blue leather loveseat	1
15	Blue padded rolling chair	1	30	Wooden kiosk computer cabinet	1
16	3 Gray padded rolling chairs	1	31	Wood & metal desk	1
17	Gray padded rolling chair	1	32	11ft x 8ft Dining canopy	1
18	Gray padded rolling chair	1	33	Wooden desk	1
19	Black leather hi-back rolling chair	1	34	Formica top metal desk	1
20	Black leather rolling chair	1	35	3-tier Literature/book rack/display	1
21	Gray padded rolling chair	1	36	Small rolling computer desk	1
22	2 Gray padded hi-back rolling chairs	1	37	Metal desk	1
23A	Black leather & wood reception chair	1	38	Small wooden table	1
23B	Black leather & wood reception chair	1	39	Wooden coffee table	1
23C	Black leather & wood reception chair	1	40	Wooden coffee table	1
23D	Black leather & wood reception chair	1	41	GE Television w/ rabbit ears	1
23E	Black leather & wood reception chair	1	42	Magnavox TV	1
23F	Black leather & wood reception chair	1	43	Wooden end table	1
23G	Black leather & wood reception chair	1	44	Large convertible coffee table	1
23H	Black leather & wood reception chair	1	45	Large wooden & wicker coffee table/chest	1
24A	Gray cloth & metal chair	1	46	4-Shelf book shelf	1

LOT #	QTY	LOT #	QTY
47	2	79E	1
48	2	79F	1
49	2	80A	1
50	1	80B	1
51	1	80C	1
52	1	80D	1
53	1	80E	1
54	1	80F	1
55	1	81A	1
56	1	81B	1
57	1	81C	1
58	1	81D	1
59	1	81E	1
60	1	82	1
61	1	83	1
62	1	84	1
63	1	85	1
64	1	86	1
65	1	87	1
66	1	88	1
67	1	89	1
68	1	90	1
69	1	91	1
70	1	200	1
71	1	201	1
72	1	202	1
73	1	203	1
74	1	204	1
75	1	205	1
76	1	206	1
77	1	207	1
79A	1	208	1
79B	1	209	1
79C	1	210	1
79D	1	211	1

LOT #	QTY	LOT #	QTY
212	1	238	1
Headlight alignment tester		15-0032	
213	1	Breakerless Ignition Tester	
Grinder		239	1
214	1	T83L-19000-A	
Wooden cabinet shelf		Air Conditioning Service Kit	
215	1	240	1
Cutting torch with 2 tanks, rolling cart		Helicoil Master Thread Repair Kit (Part# 5522)	
216	1	241	1
Evaporative emission system tester w/ tank on rolling cart		T97L-1000-FH/FLMH	
217	1	Essential service tools to be used w/ TKIT-1997-FH/FLMH	
Roughneck pumpless oil receptacle		242	1
218	1	T83T-1000-F	
Purewash parts washer		Axle transmission kit	
219	1	243	1
Vital 2-ton chain hoist		T78P-3504-A	
225	1	Steering gears and pump service set	
TKIT-1973 1/2-J		244	1
Courier automatic transmission service kit		T74P-6000-L	
226	1	2.3 L Engine service kit	
007-00086		245	1
MLP adapter kit		T83T-4000-A	
227	1	Axle service kit	
007-0041A		246	1
Super Star II		TKIT-2007AC-FLM	
228	1	2008 Escape/Mariner	
ST-270 12270		247	1
Cooling system pressure tester		TKIT-2007AP-F	
229	1	6.4 L diesel essential	
T80L-50-EEC-2		248	1
1980 electronic engine tester		T73T-1200-A	
230	1	Front wheel tool group	
Speed control tester		249	1
231	1	78-0100	
TKIT 1984-D2.0		Diesel tach / timing meter	
Diesel essential service kit		250	1
232A	1	TKIT-1992-FH/FMH, -FLMH	
TKIT-2006UF-FLM (box 1 of 4)		Transmission air test plate, TR sensor alignment gauge, Servo Piston remover/installer, VRV setting block, Valve guide installer	
RDU Bushing (70MM) Installer, RDU Bushing (65MM) Installer, RDU Bushing (60MM) Installer, Forward Clutch Spring Compressor, Conv. Housing Seal Installer, Transfer Gear Bearing Installer, Transfer Gear Bearing Remover, Inp. Sft. Support Seal Installer, Support Solid Seal Installer, Transmission Bracket, Manual Shaft Seal Installer, Cover Axle Seal Installer, Case Dam Seal Installer, 2-6 Spring Compressor, Support Seal Installer, Bearing Remover, Differential/Transfer Bearing Isnt/Guide, Rev Clutch Piston, Compressor, O/D Clutch & Balance Piston Tool, Shim Selection Tool, Manual Lever Retaining Pin Installer, Seal Installer, Engine Lift Eye, Engine Support Bar, VCT/Spark Plug Seal RR Tools, Camshaft Holding Tools, Valve Spring Compressor Brackets, Rear Main Seal Installer, Front Seal Installer, Stretchy Belt Remover/Installer Tool		251	1
232B	1	007-00097 TFI-IV Diagnostic Cable	
TKIT-2006UF-FLM (box 2 of 4)		part of TKIT-1991-FH/FMH,-FLMH,-LTH,-MH	
See description Lot #232A		252A	1
232C	1	TKIT-1977-S	
TKIT-2006UF-FLM (box 3 of 4)		Fiesta special tool set (box 1of 2)	
See description Lot #232A		252B	1
232D	1	TKIT-1977-S	
TKIT-2006UF-FLM (box 4 of 4)		Fiesta special service tool set (box 2 of 2)	
See description Lot #232A		253	1
235	1	T85T-6000-D2.3	
T85L-1000-8		Essential 2.3L diesel service tools	
Essential service tools		254	1
236	1	Analog tachometer model 36	
T77L-9500-A		255	1
Model 2700 VV Carburetor Service Set		Anti-lock break system service module	
237	1	256	1
Super Star II		134-R0080 Fuel line tool	
		257	1
		TKIT-1994-FH/FLMH	
		Subframe alignment pins, Powertrain alignment gauge, Gearshift lever aligner, Dial indicator gauge holding fixture, Input shaft oil seal installer, Shaft bearing cup installer, Differential oil seal installer,shifter shaft bearing remover/installer, Input shaft socket, Shim selection set, Servo plug remover/installer, Camshaft alignment plate, Water inlet tube installer, Valve stem oil seal remover, Valve guide installer, Valve guide installer, Valve spring compressor, Fuel injector remover, Water pump pulley service set	
		258	1
		T74P-3000-A	
		Caster-camber adjustment wrenches	

LOT #		QTY	LOT #		QTY
259	T76T-1200-AB Econoline rear axle hub tools	1	280	1981 Escort/Lynx Suspension, hub and brake tools	1
260	T78P-4200-A 7.5 Rear axle service set	1	281	T80L-77000-A Auto O/D transmission service set	1
261	TKIT-1983-D6.9 Crankshaft gear service set, Fan pulley holding wrench, Fan clutch nut wrench, Crankshaft timing sprocket/vibration damper installer, Tappet bleed wrench, Valve spring compressor, Valve guide oil seal installer, Crankshaft rear oil seal installer, Crankshaft rear oil seal protector, Transfer pump pressure gauge, Fuel injection pump nounting wrench, Fuel injection pump rotator, Fuel system openings protector, Fuel line socket, Intake manifold opening protector, Diesel nozzle seat reamer	1	282	T77L-7025-F Transmission rug-BP bearing service set	1
262	TKIT-2005-F Essential kit for Escape AK, CD4E and PTO service	1	283	TKIT-1982-F Coil spring compressor, Portable press frame fixture, Locknut socket, Mainshaft front bearing installer, Distributor hold down clamp wrench set, Transmission air test plate, Piston seal protector, Transmission air test plate, Transmission test plate screw set, Crankshaft vibration damper installer, Crankshaft vibration damper remover, Tappet bleed wrench, Crankshaft rear main oil seal installer, Camshaft timing sprocket remover	1
263	T80T-4000-8 Front axle service set	1	285	TKIT-1972-HT Automatic transmission service kit	1
264	T-71T-3010-A Front drive axle service kit	1	286	TKIT-1972-J Courier truck service kit	1
265	TKIT-2003N-F Diesel essential service tool kit	1	287	T88T-7025-S Part of TKIT-1988-F/LT/FLM	1
266	T79P-4020-F Pinion depth gauge service set	1	288	T83P-1000-FDH Shim selection tool, Front hub bearing remover/installer, Locknut adjusting wrench, Carrier bearing puller collet, Carrier bearing puller collet, Metric hub removal adapters, Differential bearing installer, Differential bearing cone installer, Constant velocity joint dust seal installer, Cluster gear bearing installer, Heater control cable disconnect tool, Vacuum regulator valve setting gauge block	1
267	014-00761 Vacuum pressure tester	1	289	TKIT-1972-J Courier truck service kit	1
268	1981 Escort/Lynx Manual trans-axle, differential, and clutch service tools	1	290	1981 Escort/Lynx engine service tools	1
269	1981 Escort/Lynx Climate control tools	1	291	TKIT-1982-FH Twin I-beam pivot bushing gauge, steering gear locknut wrench, Steering gear bearing service set	1
270	007-00110 Distributor/less ignition system tester	1	292	T96P-1000-A Part of TKIT-1996-F	1
271	T88C-3504-S 3 of 5 part of TKIT-1988-FH/FLMH	1	293	T74P-3504-A Rack and pinion power steering service kit	1
272	TKIT-1983-D2.2 Diesel nozzle seat reamer	1	294	T74P-77000-A C-3 transmission service set	1
273	T95P-1000-FH/FLMH Crankshaft rear oil seal assembly service installation tool kit	1	295	007-000057/007-00058/007-00059 Part of TKIT-1990-F/FM/FLM, Diagnostic harness	1
274	T79P-3044-AX Front suspension service set	1	296	T74P-6000-V 2.8L v-6 engine service kit	1
275	T75L-7025-A Transmission bearing service set	1	297	T98L-1000-F/FM TKIT-1998-F/FM, Essential service kit	1
276	T89T-70000-A Part of TKIT-1989-F/FM/FLM/HT/TL, Automatic transmission essential service tools	1	298	014-00950 104 PIN EEC-V breakout box	1
277	T80T-4020-F 1980 pinion depth gauge service set	1	299A	TKIT-2006SD-FLM (box 1 of 3) Oil supply block off plug, Fuel injector sleeve brushes, EGR valve cleaning brush, Crankshaft seal installer, Crankshaft seal remover, 6.4L injector cups, Lifting bracket, EGR puller, EGR cooler test plates, LP turbo to HP turbo seal installer, Fuel injector connect/disconnect tool, Fuel system caps, Fuel line adapter	1
278	1981 Escort/Lynx Automatic trans-axle tool	1			
279	T80L-50-EFI 1980 electronic tester adapter cables	1			

LOT #	QTY	LOT #	QTY
299B TKIT-2006SD-FLM (box 2 of 3) See Lot 299A	1	hub nut socket, Drive pinion bearing installer, Drive pinion bearing installer, Drive pinion flange installer, Transmission extension housing bushing remover, Transmission extension housing bushing installer, Steering gear oil seal service set	
299C TKIT-2006SD-FLM (box 3 of 3) See Lot 299A	1		
300A T94T Incomplete essential tool set - no label	1	319 Set T86P-1000-S	1
300B T94 SET	1	320A T99T-1000-A (part of TKIT-1999-F/FLM/LT) Transmission essential tool kit	1
302 TKIT-1972-AT AT-540 automatic transmission service kit	1	320B T99T-1000-B TKIT-1999-F/FLM/LT--See description of lot 320A	1
303 T88L-1000-SF Part of TKIT-1988-FH	1	320C T99T-1000-C (TKIT-1999-F/FLM/LT) See description of lot 320A	1
306 D93L-19703-B Air conditioning test fitting set	1	320D T99T-1000-D (part of TKIT-1999-F/FLM/LT) See description of lot 320A	1
307 007-00044 part of TKIT-1989-F/FLM/FM/LM/LT/M DIS diagnostic harness	1	320E T99T-1000-E (part of TKIT-1999-F/FLM/LT) See description of lot 320A	1
308A T88C-77000-C (part of TKIT-1988-FH/FLMH) Shim selection set	1	321 TKIT-1984-F Differential rotator, Differential clutch gauge, Shift shaft bearing remover/installer, Bearing tube removal screw, Linkage grommet installer, Front cover aligner, Cylinder head aligner, Exhaust manifold aligner, Fan pulley holding wrench, Fan clutch nut wrench, Purge line air flow gauge	1
308B T88L-1000-SA (part of TKIT-1988-FH/FLMH) Essential tool kit	1	322 T88L-1000-A (part of TKIT-1988-F) Essential service kit	1
309A T88C-1000-F (part of TKIT-1988-Festiva) Festiva service kit used w/ T88C-1000-SF service kit & T88C-77000-JF shim selection kit	1	324 TKIT-2006C-F/FM/FLM Essential service tools kit	1
309B T88C-1000-SF (part of TKIT-1988-Festiva) See description of lot 309A	1	325 T88T-1000-S (part of TKIT-1988F/LT/FLM) Axle tool kit	1
309C T88C-77000-JF (part of TKIT-1988-Festiva) Shim selection kit--See description of lot 309A	1	326 T87T-7025-SH (part TKIT-1987-FLMH/LTH) Transmission service set	1
310 T79P-4200-A Rear axle service set	1	327 T87L-1000-S (part of TKIT-1987-FLM) Brakes, steering tool kit	1
311 1981 Escort/Lynx TRW rack and pinion tool	1	328 T88P-1000-S (part of TKIT-1988-F) Anti-lock brake kit & oil seal pilot essential service kit	1
312 TKIT-2007FA-FLM Fuel pressure test adapter & Edge/MKX tools	1	330 T90T-1000-A (part of TKIT-1990-F/LT/FLM) Seal & axle tools	1
313 TKIT-2005S1-F Mustang hub tools	1	331 Transmission roll pin extractor kit	1
314 TKIT-1986-FLMH Adapter for 204-S127, Adapter for 204-S127, Adapter for 204-S127, Front wheel hub oil seal installer, Drive pinion outer bearing remover, Output shaft oil seal installer, Fluid cooler line remover, Axle tube oil seal installer, Axle tube oil seal installer, King pin seal installer, Drive pinion gauge block, Differential dummy bearing gauge, Drive pinion inner bearing remover	1	332 T77J-7025-A Courier 5 speed transmission service set	1
315 Set T86P-7000-S Axod transmission service set	1	333 206-086- 0.125 coated cable tension gauge Parking brake cable adjustment gauge	1
316 Set T86T-1000-S Light truck service Sst	1	334 FPT25-00E R/G Fuel cap adapter set	1
317 TKIT-2008DT-F 6.0 diesel fuel tester kit	1	335A TKIT-2005D1-F (box 1 of 4) CVT seal tools essential service kit	1
318 TKIT 1985-FH-1 Axle bearing remover, Differential shim installer, Axle bearing remover, Axle bearing cup installer, Drive pinion depth gauge/aligner, Drive pinion aligner, Differential shim installer, Drive pinion thread protector, Wheel	1	335B TKIT-2005D1-F (box 2 of 4) See description of lot 335A	1
		335C TKIT-2005D1-F (box 3 of 4) See description of lot 335A	1
		335D TKIT-2005D1-F (box 4 of 4) See description of lot 335A	1

LOT #	QTY	LOT #	QTY
336	1	364	1
T93P-1000-A (part of TKIT-1993-F,FM/FLM) Essential service tools		T94P-77000-A1 (part of TKIT-1994-F&FLM/FM) CD4E Transmission service tool kit	
337	1	365	1
T87P-4000-S (part of TKIT-1987-FLM/LM) All wheel drive essential service set		T88C-7000-S (part of TKIT-1988-FH/FLMH) Transaxle service tools kit	
338	1	366	1
T87T-7000-S (part of TKIT-1987-FLM) Truck tool service kit		T99L-1000-D (part of TKIT-1999A-F/LT) Engine & hub service tools	
339	1	367	1
Part of TKIT-1992-FH/FMH Essential service tool kit		T98P-1000-B (part of TKIT-1989-F/FM) Essential service tools kit	
340	1	370	1
T93L-1000-FH/LTH TKIT-1993-FH/LTH, Essential service tool kit		007-00103/007-00580 (part of TKIT-1994-F/FM/FLM/LT) Essential service tools	
341	1	371	1
TKIT-1990 1/2 FH/FLMH/LMH/MH Engine & transmission service tools		OW-C6503 Power steering pump pulley service set	
342	1	372	1
T90P-1000-A (part of TKIT-1990-F) Essential service tool		14mm spark plug thread repair kit	
343	1	373	1
T89P-1000-A (part of TKIT-1989-F/FM/FLM/LM) Axle essential service tool		Tubing tool set	
344	1	374	1
T91P-1000-FH/FMH (part of TKIT-1991-FH/FMH,-MH) 4.6L Engine air suspension service tools		TKIT-1992 1/2 FH/FLMH/FMH Transmission air test plate, TR sensor alignment gauge, Servo piston remover/installer, VRV setting block, Valve guide installer	
345	1	375	1
19-002 Pressure test kit		T93P-1000-F (part of TKIT-1993-F) FE series Topaz/Taurus tool kit	
347	1	376	1
T97L-1000-SH (part of TKIT-1987-FLMH) Essential Service tools		TKIT-2000-F/FM/FLM Drive pinion oil seal installer, Passenger air bag diagnostic service tool, Side air bag diagnostic service tool, Halfshaft remover, Spring washer compressor, Torque converter clutch gauge, Transmission mounting bracket, Vent tube installer, Air test plate gasket, Final drive input gear holding tool, Final drive input nut socket, Transmission range sensor alignment tool, Transmission band select gauge, Differential/transfer gear bearing shim gauge, Transfer gear bearing cup installer, Wrench guide plate, Torque converter leak tester, Halfshaft oil seal installer, input shaft snap ring installer, Input shaft fifth gear remover	
348	1	377	1
T89P-1000-E (part of TKIT-1989-F) Festiva transaxle tool kit		TKIT-1999S-FLM/LT Clutch alignment tool, Fuel tank lock ring wrench, Drive pinion bearing cup installer, Drive pinion thread protector, Drive pinion bearing installer, Drive pinion inner bearing remover	
351	1	378	1
T90P-1000-FH/FLH/FLMH Escort/Tracer/Festiva engine & A/C tools		TKIT-2000RFLM Transmission direct clutch outer fluid seal protector, Transission forward clutch outer fluid seal protector, Transmission reverse clutch outer fluid seal protector, Transmission reverse clutch inner fluid seal protector, Transmission solenoid connectors gauge	
352	1	379	1
TKIT-2006UP-FLM 07 Expedition/Navigator ESST Bushing tools for Expedition or Navigator		TKIT-2004Q3-F 7.3L/6.0L diesel tool kit	
353	1	383	1
TKIT-1000-D (part of TKIT-1990-F/FM/FLM/LM/M) A/C fitting essential service kit		Electronic battery tester	
354	1	384	1
T89P-6000-A (part of TKIT-1989-F/FM/FLM) V6 engine tool kit		TKIT-2006EFT-FLM Exhaust flange essential tool kit	
357	1	385	1
T95T-1000-F/FLM/LT Explorer Dana 35 axle service tools		TKIT-2006SP-FLM 5.4L 3V Engine S/P ESST Spark plug tool kit	
358	1	386	1
T97L-1000-F/FM Essential service tool kit		T99T-1000-F (part of TKIT-1999M-F) Essential service tool set	
359	1	388	1
T95L-1000-F Truck Dana axle essential service tool kit		T97-1000-A (part of TKIT-1997-F/FM) Essential service tool	
361	1		
TKIT 1985-FH-2 Axle bearing remover, Differential shim installer, Axle bearing remover, Axle bearing cup, Drive pinion depth gauge/aligner, Drive pinion aligner, Differential shim installer, Drive pinion thread protector, Wheel hub nut socket, Drive pinion bearing installer, Drive pinion bearing installer, Drive pinion flange installer, Transmission extension housing bushing installer, Steering gear oil seal service set			
362	1		
T94P-77000-A2 (part of TKIT-1994-F&FLM/FM) CD4E transmission service tool kit			
363	1		
T94P-1000-FH/FLMH (part of TKIT-1994-FH/FLMH) Essential service tools			

LOT #	QTY	LOT #	QTY
389 T97T-1000-A (part of TKIT-1997-F/FLM/LT) Used on transmissions & F-series engines	1	401 TKIT-2002D-FLM Tire pressure monitor activation tool, Transmission fluid pump seal installer tools, Flywheel locking tool, Front differential housing bushing remover/installer, Rear differential housing bushing remover/installer, Halfshaft remover, Outer constant velocity joint dust shield installer, Inner constant velocity joint dust shield installer	1
390 TKIT-1996-F/FM/FLM Adapter for 204-185, Ring gauge (0.165"), Ring gauge (0.225"), Differential housing (plate) spreader, Drive pinion gauge tube, Differential bearing gauge, Differential bearing gauge, Countershaft bearing remover, Input shaftoil seal installer, Output shaft oil seal installer, Shaft oil seal protector, Transmission extension housing bushing service set, Piston seal protector, Flywheel holding tool, Camshaft position aligner, Crankshaft rear oil seal installer, Crankshaft rear oil seal service set, Wheel knuckle oil seal installer, Needle bearing installer, Axle turning torque socket, Axle shaft deflector installer, Front axle shaft oil seal installer, Front axle shaft bearing installer, Adapter for differential housing spreader, Front axle mounting bushing installer, Front axle mounting bushing cup remover, Front axle mounting bushing collet installer, Front axle mounting bushing installer, Front axle mounting bushing Drawbolt installer, Front axle mounting bushing remover, Front axle mounting bushing remover, Bearing preload gauge	1	402 TKIT-2003N-F 6.0L diesel engine tool	1
391 TKIT-1996-F/FM/FLM See description of lot #390	1	403A TKIT-2005D2-F (box 1 of 3) 2005 CVT 6HP26/6R60 Transmission essential service kit	1
392 T96P-1000-FH/FLMH (part of TKIT-1996-FH/FMH/FLMH) 3.4 L SHO engine tools	1	403B TKIT-2005D2-F (box 2 of 3) See description of lot 403A	1
393 014-00930 7.3L DIT Engine mandatory equipment	1	403C TKIT-2005D2-F (box 3 of 3) See description of lot 403A	1
394 TKIT-1995-F/FM/FM/LT/FLM Torsion bar remover/installer, Input shaft oil seal installer, Transmission air test plate gasket, Torque converter aligner, Clutch housing aligner, Valve body aligner, Valve body aligner, Piston seal sizer, Piston seal sizer, TSS gauge, Piston seal sizer, Servo cover compressor, Transmission front pump staking tool, Valve guide installer, Valve stem oil seal installer, Front axle bearing installer, Front axle bearing installer, Front axle bearing installer, Front axle wheel hub nut (2 1/2") socket, Front axle wheel hub nut (2 3/4") socket, Front axle oil seal installer, Differential housing spreader adapters, Drive pinion bearing cup remover, Differential plug set	1	404 TKIT-2000-F/FM/FLM Drive pinion oil seal installer, Passenger air bag diagnostic service tool, Side air bag diagnostic service tool, Halfshaft remover, Spring washer compressor, Torque converter clutch gauge, Transmission mounting bracket, Vent tube installer, Air test plate & gasket, Final drive input gear holding tool, Final drive input nut socket, Transmission range sensor alignment tool, Transmission band select gauge, Differential/transfer gear bearing shim gauge, Transfer gear bearing cup installer, Wrench guide plate, Torque converterleak tester, halfshaft oil seal installer, Input shaft snap ring installer, Input shaft fifth gear remover	1
395A TKIT-2008ET-FLM (box 1 of 4) Truck 4X4 complete service kit	1	405A TKIT-2005P-F (box 1 of 3) Front axle vacuum hub kit	1
395B TKIT-2008ET-FLM (box 2 of 4) See description of lot 395A	1	405B TKIT-2005P-F (box 2 of 3) See description of lot 405A	1
395C TKIT-2008ET-FLM (box 3 of 4) See description of lot 395A	1	405C TKIT-2005P-F (box 3 of 3) See description of lot 405A	1
395D TKIT-2008ET-FLM (box 4 of 4) See description of lot 395A	1	407 T83L-50-EEC-IV Electronic engine control breakout box	1
399 T96L-1000-A (part of TKIT-1996-F/FM) F-series & Explorer essential service tools	1	408 007-00116 Breakout box adapter	1
400 TKIT-1995-FH/FLMH Air spring remover, Front differential housing bushing remover, Front differential housing bushing installer, Front differential housing bushing aligner, Front differential housing bushing installer, Front differential housing bushing remover, Rear suspension bushing remover/installer, Compressor clutch holding fixture, Transmission air test plate, Retaining ring pliers, Crankshaft rear oil slinger remover, Crankshaft rear oil seal installer, Crankshaft rear oil slinger installer, Crankshaft rear oil seal installer, Crankshaft rear oil seal remover, Disc brake spring compressor	1	410 T94L-1000-FH (part of TKIT-1994-FH) AX4N transmission tool kit	1
		411A TKIT-2006U-F/FM (box 1 of 3) Exhaust system essential tools	1
		411B TKIT-2006U-F/FM (box 2 of 3) See description of lot 411A	1
		411C TKIT-2006U-F/FM (box 3 of 3) See description of lot 411A	1
		412 TKIT-2003D-TBIRD Axle & differential tools	1
		413 TKIT-2004J-F Truck essential service tools	1
		414 Disk brake rotor gauge	1
		415 TKIT-2001-FLM Adapter for 205-001, Drive pinion nut socket, Restraint system diagnostic service tool, Restraint system diagnostic service tool, PTO shaft inner/outer oil seal installer, PTO driven gear oil seal remover, PTO driven gear oil seal installer, Halfshaft oil seal installer, PTO dust flange installer, RH	1

LOT #	QTY	LOT #	QTY
halfshaft fluid seal installer, RH halfshaft fluid seal remover, Drive pinion nut holding tool		431	1
417	1	TKIT2005D2-F1	1
Essential service tool set		Essential service tools	
418	1	433	1
007-00075 Distributor/less ignition system tester		Injector rack & sleeves	
419	1	434	1
TKIT-2002N-DEW		Box of misc. diagnostic tools	
Transmission fluid pump remover, Transmission fluid pump alignment pins, Transmission fluid pump alignment pins, Gauge bar, Cushion spring compressor, Servo cover compressor, Flex plate aligner, Output shaft flange installer, Differential bushing remover/installer		434A	1
420	1	TKIT-2006SD-Q1	1
TKIT-2002-F/FM		Diesel essential tools	
Input shaft holding fixture, Transmission fluid pump alignment gauge, Transmission fluid pump alignment gauge, Transmission air test plate & gaskets, Forward clutch seal gauge, Extension housing seal installer, Transmission fluid fill tool, Transmission cooler line disconnect tool, Crankshaft holding tool, Halfshaft remover, Halfshaft pilot bearing installer, Halfshaft seal installer, Halfshaft seal protector, Axle bushing remover/installer, Axle bushing receiving cup, Outer constant velocity joint dust shield installer, Inner constant velocity joint dust shield installer		434B	1
421	1	303-F694	1
1999 Essential special service tools (no tag)		Lift bar adapter	
421A	1	434C	1
TKIT-2006PT-FLM/ TKIT-2006PT-ROW		6.0L Oil pressure leak tester	
Oil pan support for 3.0L & 3.5L Duratech		435	1
421B	1	Tow bar	1
TKIT-2004M-F		436	1
Essential service tools		Slide hammer & accessories	
422	1	437	1
T85T-1000-A		Box of misc. tools, wires, wheel center caps	
Ranger & Bronco 4X4 service kit		438	1
423	1	Block leak tester	1
TKIT-2003N-F		438A	1
6.0L diesel engine tool kit		TKIT-2005F-F	1
424	1	Escape transmission tools	
1986 Escort/Lynx/Sable steering tool service set		438B	1
425	1	TKIT-2007AC-F	1
TKIT-2002N-F/FM		Refrigerant flushing connector tool	
Input shaft holding fixture, Transmission fluid pump alignment gauge, Transmission fluid pump alignment gauge, Transmission air test plate & gaskets, Forward clutch seal gauge, Extension housing seal installer, Transmission fluid fill tool, Transmission cooler line disconnect tool, Crankshaft holding tool, Halfshaft remover, Halfshaft pilot bearing installer, Halfshaft seal installer, Halfshaft seal protector, Axle bushing remover/installer, Axle bushing receiving cup, Outer constant velocity joint dust shield installer, Inner constant velocity joint dust shield installer		438C	1
426	1	Box misc. brake tools	1
TKIT-1994-FH/LTH		439	1
Flexible exhaust pipe holding fixture, Crankshaft vibration damper wear ring remover, Crankshaft vibration damper wear ring installer, Crankshaft vibration damper wear ring remover, Crankshaft rear wear ring remover, Crankshaft rear wear ring guide, Crankshaft rear oil seal installer, Crankshaft rear oil seal installer, Fuel injector remover, Fuel injector installer		Support	
427	1	440	1
1992 Essential special service tools (no tag)		Box misc. parts	
428	1	441	1
MST4530 Power steering pump pulley set		Box misc. parts and tools	
429	1	442	1
Slide hammer puller set		Chicago Pneumatic CP-797 air wrench w/ accessories	
430	1	443	1
Electronic wheel balance-indicator		Box misc. lug wrenches and grease gun	
		444	1
		Valve assembly, fuel fill	
		445	1
		TKIT-2005GT-F	1
		Audio unit remover	
		446	1
		Box of wrenches	
		447	1
		TKIT-2005U-F	1
		Differential seal protector	
		448	1
		TKIT-2003A-F	1
		Fuel draining hose	
		449	1
		Box of misc. vacuum test tools	
		450	1
		TKIT-2007FI-FLM 5.4 L	1
		Injector test essential tool	
		451	1
		Box of misc. special tools	
		452	1
		Multimedia tester	
		453	1
		Fuel cap tester	
		454	1
		Axle spreader	
		499	1
		Roughneck pumpless oil drain receptacle	
		500	1
		Ammco 4000 brake lathe	
		501	1
		Shop fan	
		502	1
		Wooden work bench	

LOT #	QTY	LOT #	QTY
503	1	625	1
Craftsman rolling tool box		Oil barrel with hand pump	
504	1	626	1
Metal work bench w/ vise		Vital 2-ton chain hoist	
505	1	700	1.01
Metal work bench w/ vise		Craftsman toolbox w/ 2 homemade jack stands	
506	1	701	1
Metal work bench w/ vise		Oil Ace oil receptacle	
507	1	702	1
Coats 4050A tire mounting machine		2 Propane bottles	
508	1	703	1
Gray metal cabinet		Rolling cabinet	
509	1	704	1
5 Oil drain pans		Lift Distributors of America- 9k lb - 2-post lift	
510	1	705	1
Coats 1250 wheel balancer		Norco transmission jack	
511	1	706	1
Rotary 12000 lb 4-post lift w/ 1 new post		Metal work bench w/ vise	
512	1	707	1
Air compressor		5k lb Air Jack- Lincoln	
513	1	708	1
Champion air compressor		Purewash parts washer	
600	1	709	1
3 Valcom PA horns		Rolling shop fan	
601	1	710	1
2 Valcom PA horns & 1 Speco PA horn		30k lb Grand 4-post lift	
602	1	711	1
5 Hose reels w/ air hoses		Engine stand	
603	1	712	1
3 Screw and bolt bins		Rotunda R-134 recovery machine	
604	1	713	1
2 Screw and bolt bins (1 gray, 1 yellow)		Vital 2-ton chain hoist	
605	1	714	1
Box of 12 fire extinguishers		Vital 2-ton chain hoist	
606	1	715	1
Emergency eyewash station		Box of misc. bottle jacks, chain, and jack stand	
607	1	716A	1
Rotunda 20-ton press and accessories		Metal desk	
608	1	716B	1
Vital 2-ton chain hoist		Wooden desk	
609	1	716C	1
Shop fan		Wooden bookshelf	
610	1	716D	1
Metal work bench w/ vise		Metal desk	
611	1	716E	1
Air tank		2-Drawer file cabinet	
612	1	716F	1
Set of 4 hub caps		Lexmark printer	
613	1	716G	1
Craftsman 15 1/2 inch drill press		Genicom printer	
614	1	716H	1
Box of: 2 bottle jacks, 1 grease gun, radio		Flower print cloth loveseat	
615	1	716I	1
Lincoln 4-ton floor jack		Brown cloth rolling chair	
616	1	716J	1
Metal work bench w/ vise		Rolling cloth arm chair	
617	1	716K	1
Wall cabinet with carburetor kits		Round wall thermometer	
618	1	716L	1
2 Vacuum hose racks & 1 hose clamp rack		2 Phones	
619	1	716M	1
Pro-Cut on-car brake lathe		Blue leather loveseat	
620	1	716N	1
Yellow Jacket refrigerant management system		Brown rolling chair	
621	1	716O	1
Rotunda/Hunter alignment rack		Brown chair	
621A	1	717	1
2 shelves, metal cart, BBQ grill, table, fan, hose		Cargo van shelving & accessories	
622	1	718	1
4000 lb Hydraulic floor jack		Box of misc. tools	
623	1	719	1
1500 lb Cap. engine hoist		Box of misc. tools	
624	1	720	1
Heavy duty long ram jack engine stand		Eyewash station	
		721	1
		3 Hose reels w/ air hose	

LOT #		QTY
722	Napa Model 85-1010 battery charger	1
723	Big Country brush guard	1
724	Homemade engine stand w/ weedeater	1
725	Custom headache rack	1
726	Box of misc hoses and gauges	1
727	Vise	1
728	Craftsman air compressor -60 gal.	1
729	Compressor (outside)	1
730	Tire rack w/ 53 used tires & assorted rims	1
731	Lift Distributors of America 9k lb lift	1
